

AGRI-AIDE® Ventilation

Assembly Instructions

The FC3100 Damper is specifically designed for use with the Osborne Agri-Aide FC3000 fiberglass roof cupola. For best results, please read and follow these instructions carefully.

| ASSEMBL | V INSTE | LICT | SMO |
|----------------|---------|----------|--------------|
| ACCEIVIDE | | \cdots | \mathbf{c} |

- Remove the damper assembly and hardware from shipping carton. Inspect the parts for damage. If damage is found report to delivering carrier immediately. Compare quantity and parts received against the parts list at right.
- Remove 2 solid plastic snap bushings from one half of the FC3000 roof cupola. Replace the 2 solid bushings with the 2 hollow bushings included in the hardware kit. (See Figure 1.)
- Insert the 1/8-in nylon rope through the pre-drilled holes in the damper assembly and through the aluminum washer. Tie a SECURE knot in the end of the rope. (See Figures 1 and 2.)
- 4. Remove the 1/2-in diameter solid rod from the center of the damper assembly. Install the insulated damper panel inside the cupola. NOTE: The position of the hole located 5-in from the edge of

| FIGURE 1 | |
|---|---|
| | Fiberglass Roof Cupola FV-FC3000 Solid Snap Bushing Hollow Snap Bushing RFM-7400 Cotter Pin |
| Insulated Panel SV-FC3101 | 3/16-in Washer RFW-0923 |
| 1/8-in Nylon Rope 15-ft Long RFM-2100 | 5-in |
| 1/4-in x 2 1/4-in Screw Eye RFS-1760 | 1/2-in Diameter Solid Rod SV-FC3102 |

| Parts List | | | | |
|------------|-------------|-----------------------------|-----|--|
| Item | Part Number | Description | Qty | |
| 1 | KV-FC3100 | Damper Assembly | 1 | |
| 1A | SV-FC3101 | Insulated panel | 1 | |
| 1B | SV-FC3102 | 1/2-in solid rod | 1 | |
| 2 | SV-FC3115 | Hardware Kit — Damper | 1 | |
| 2A | RFM-7400 | Hollow snap bushing | 2 | |
| 2B | RFM-3217 | Cotter pin | 2 | |
| 2C | RFS-1760 | 1/4-in x 2 1/4-in screw eye | 1 | |
| 2D | RFM-2100 | 1/8-in nylon rope | 15' | |
| 2E | RFW-0923 | 3/16-in aluminum washer | 1 | |

the panel must be placed inside the cupola first and the knot positioned towards the center of the cupola. (See Figures 1 and 2.)

- Carefully thread the 1/2-in solid rod through the hollow snap bushing, through the insulated panel, and out the other hollow snap bushing. Secure the ends of the rod using the cotter pins provided. (See Figure 1).
- 6. Install the screw eye hook in a convenient place to tie the damper adjustment rope to after selecting the desired damper position.



