

FIRE IFC Display

The display serves multiple functions which include a status indicator to display the current station operation, and as a visual feedback to the operator for setup and/or diagnostic purposes.

Left Digit – Trough refill mode (Topup mode)

- 0 – Trough weight OK
- 1 – Need to refill, verifying initial weight
- 2 – Dispenser turned on
- 3 – Dispenser turned off
- 4 – Refilling ended, verify end weight and update DPC value

Middle Digit – Normally blank

Displays number of dispenser revolutions made during trough refilling


Right Digit – Event mode

- 0 – Event in progress (animal considered eating)
- 1 – no event in progress

Left Decimal point – Trough steady light

Middle Decimal point – Platform steady light

Right Decimal point – Run light (flashing continuously)



FIRE Feeder IFC Numerical Display with Decimal Indicators